SEAT BELT REPLACEMENT NOTICE

CAUTION

Installation of a 3—point seat belt must be only in a vehicle where a 3—point seat belt had been previously installed or where mounting points have been designed, TESTED AND QUALIFIED BY THE 0FM to meet FMVSS 210.

A 2—POINT SEAT BELT MUST BE INSTALLED in a vehicle where a 2—point seat belt had been previously installed.

IMPORTANT NOTICE

The belt is only interchangeable in vehicles as a complete unit. DO NOT change half of the belt or parts of system. This will void the warranty and could lead to an extreme safety hazard. When replacing a seat belt system be sure to:

- 1 Replace the entire seat belt, buckle—side and hardware.
- 2 Insert the latch on the belt into the buckle to determine if it works properly after belt is installed.
- 3 Always read and follow the installation instruction guide included with or attached to each belt to ensure proper installation.

Indiana Mills and Manufacturing, Inc. is not responsible for improper installation, application or use of this product.

See reverse side of the orange tag for identification of specific vehicle and seat position for which this belt has been designed.

